


WNAM 1.4 Wi-Fi (,), , .. - Wi-Fi, .

WNAM , , ():



(" " " ") WNAM, : /cp/authbyext , (POST) : username password. WNAM (..) HTTP REST API. " - " :

extcheck_user	WNAM (HTTP REST) Basic Auth
extcheck_password	WNAM (HTTP REST) Basic Auth
extcheck_uri	URL HTTP REST Wi-Fi

(support@netams.com).